








KAT Combi

For combi tracks. For horizontal use.



► Length



1 - Length / Adjustment range	2 - Product identification sticker	Order code
<p>BC 900: Adjustment lengths from min. 650 to max. 2510 mm – 70 mm adjustment range. Adjustment range from xxxx - xxxx needed by order</p> 	 <p>PL 600 BC 900</p>	<p>511303 KAT Combi 900 xxxx - xxxx mm</p>
<p>BC 1100: Adjustment lengths from min. 650 to max. 2510 mm – 70 mm adjustment range. Adjustment range from xxxx - xxxx needed by order</p> 	 <p>PL 1000 BC 1100</p>	<p>511304 KAT Combi 1100 xxxx - xxxx mm</p>
<p>BC 2800: Adjustment lengths from min. 650 to max. 2520 mm – 40 mm adjustment range. Adjustment range from xxxx - xxxx needed by order</p> 	 <p>PL 1000 BC 2800</p>	<p>511305 KAT Combi 2800 xxxx - xxxx mm</p>

► Customized product identification sticker


✓	2 - Product identification sticker	Order code
 <p>zum Öffnen drücken push to release</p> <p>BC = 2800 daN PL = 1000 daN</p> <p>SICHERHEIT MADE IN GERMANY</p> <p>EN 12195-1</p>		<p>Customized product label with your logo</p> <p>Product label</p> <p>Custom sticker</p> <p>allsafe sticker</p>

► Sample order code

KAT Combi 2800 - 2480-2520 - allsafe sticker



KAT Combi 800





Blocking in combi tracks. Now spring-loaded for a tighter fit.



► Length



1 - Length	2 - Product identification sticker	Order code
BC 800: Adjustment lengths from min. 650 to max. 2510 mm.	 <p>Internal dimension needed by order</p> 	511302 KAT Combi 800 Internal dimension xxxx mm
	BC 800	

► Customized product identification sticker

✓	2 - Product identification sticker	Order code
  <p>BC = 800 daN</p>    	 	Custom sticker allsafe sticker

► Sample order code

KAT Combi 800 - 2200 - allsafe sticker

Heads and insert made of aluminium – especially light-weight!